

Install HDD :

2

EVOLUTION For Your Demand

Carefully following the steps to ensure correct installation.

- *** Note: If you want to install two HDDs, please set one HDD to "Master Mode" or "Single Mode", and the other one to "Slave Mode". ***
- 1) Open the upper cover of the DVR and screw out the bracket.
- 2) Screw HDD to the HDD bracket.
- Connect the HDD to power connector and IDE BUS (make sure to align the HDD precisely to the pin connection).
- 4) Close the upper cover of the DVR.

For detailed installation instructions, please refer to the user's manual.

3 **Physical Connection :** For 16 channels control for PTZ cam. IDA Camera 1 Camera 16 Main Monitor (Extend recording time with more IDA connected.) Audio in Audio 0 0 O 0 1 Internet Speaker **IR Receiver** Alarm USB Sensor Drive PC Monitor Call Monitor Adapter

System Time Setup :

EVOLUTION For Your Demand

4

Before using this unit, please set up the system time first in order to process the functions correctly.

- → Press "MENU" button to enter menu list
- → Enter the default password "0000" to access in
- \rightarrow Go to "DATE" menu and set the date
- \rightarrow Press "+" "-" button to set the correct time of the DVS
- \rightarrow Press " MENU " to exit

| DATE | | | |
|-------|--------|-------|-----|
| DATE | YEAR | MONTH | DAY |
| | 2005 | MAY | 30 |
| TIME | HOUR | MIN | SEC |
| | 15 | 30 | 18 |
| FORMA | TY-M-D | | |
| | | | |

Record & Playback :

Record:

5

Press "REC" button to go into the record menu.

RECORD MANUAL RECORD ENABLE EVENT RECORD ENABLE TIMER RECORD ENABLE OVERWRITE RECORD IMG SIZE RECORD QUALITY MANUAL RECORD IPS EVENT REOCRD IPS TIMER RECORD IPS TOTAL IPS SHARE

Playback:

Press " PLAY " button, the DVR will display the last recording video.

- FAST FORWARD (F.F.) & FAST REWIND (REW)
- PAUSE / IMAGE JOG
- STOP
- CHANNEL SHIFT
 (Display Mode, Full Screen Switch, and Channel Display Switch)
- SLOW PLAYBACK
- TMER RECORD
- AUDIO

